

You must be 18 years or older to use this product. Always wear eye protection when using this product. Follow all product operational and safety instructions. Abide by all local, state, and federal laws concerning airsoft gun use. Never aim or fire this gun at people, animals or vehicles. keep out of reach of children.

- Please use a firearm case or bag when transporting your airsoft gun.
 Disassembly and modification of this product may cause damage or unsafe operation, and voids any and all warranties.
 Treat all guns as if they are loaded. Do not put your finger on the trigger until you are ready to fire the gun.
 When not in use, always place the selector switch to safe to avoid accidental discharge.













INSTALL THE BATTERY

Handguard Type



Please Use 7.4V /11.1V Li-Polymer or 8.4V/9.6V



1.Push the Delta Ring to the rear and hold.



1.Connect the battery leads 2.Insert the battery into the lower handguard.
 3.Reinstall the Handguard.

Fixed Stock Type & Compact Fixed Stock



Please Use 7.4V /11.1V Li-Polymer or 8.4V/9.6V





Insert the Battery and Connect battery leads.



Taiwan T91 Handguarg Type



1.Remove the Pin. 2.Disassemble the Upper Handguard.



 Insert the Battery and Connect battery leads.
 Slide down the Upper Handguard with Lower Handguard.





INSTALL THE BATTERY

PDW Stock



Please Use 7.4V or 11.1V Li-Polymer Battery



1. Push Release Button and hold it .



1.Push Release Button with two side 2.Remove the stock Cap.



Insert the Battery and Connect battery leads.



Reinstall the stock Cap and stock.

Combat Crane Stock



Please Use 7.4V or 11.1V Li-Polymer Battery and 8.4V / 9.6V Ni-Mh Battery.

1.Push Release Button with two side. 2.Remove the Cover





Pistol Buffer Tube





(Crane Stock)

Please Use 7.4V or 11.1V Li-Polymer Battery Remove the EVA Grip





1.Insert the Battery and Connect battery leads. 2.Reinstall the Cover



LOADING THE MAGAZINE 9mm SMG Magazine



Put MAG CONVERTER in the receiver BEFORE you load the SMG magazine.



Pour BBs into the magazine



Wind the wheel at the bottom of the magazine until you



Load the magazine into your airsoft gun.

SHOOTING MODES



SAFE Mode

Best position Right



SEMI Mode



Full Auto Mode

AWARNING

1.Remove the battery from device when not in use. 2.Please use high quality, CE approved battery.

AWARNING Always keep finger off the trigger until you are ready to fire. Make sure the muzzle is pointing in a safe direction.

M4 300R Magazine



Pour BBs into the magazine.



Wind the wheel at the bottom of the magazine until you



AWARNING

Use SRC precision BBs only. The use of low quality BBs may cause damage to your airsoft gun.

Load the magazine into your airsoft gun.

HOP-UP ADJUSTMENT Hop-Up set to high (Rotate the Hop-Up dial towards NORMAL)

(Rotate the Hop-Up dial towards HOP)

Hop-Up set to low



Pull the Charging Handle to the rear, exposing the Hop-Up dial.

Metal Hop-Up





Hop-Up dial towards the HOPsetting.







www.starrainbow.com.tw

REAR SIGHT ADJUSTMENT



If BBs hit to the right of the target, turn windage to the



turn windage to the left.







SR4 QUICK CHANGE SYSTEM (8M/9E SERIES)









































3 Remove QC Spring Guide With Screw Driver or a Coin.





A CAUTION

The Spring is Very Powerful. Take it Out Very Carefully!



MOS-FET

- **X DOUBLE CHIP, DOUBLE PROTECTION,**
- **X OVER HEAT PROTECTION**
- ****** BUILT IN GEAR BOX, MORE ROOM FOR BATTERY

